


## RHEOSTATS WITH SAFETY TERMINALS 4mm

### MODELS 320W - 640W - 1300W - 1900W



#### ECO1/2

Rheostats 320W	
Ref.	VALUES
ECO1/2-1	0 to 1Ω / 18A
ECO1/2-10	0 to 10Ω / 5.7A
ECO1/2-15	0 to 15Ω / 4.5A
ECO1/2-33	0 to 33Ω / 3.1A
ECO1/2-47	0 to 47Ω / 2.6A
ECO1/2-220	0 to 220Ω / 1.2A
ECO1/2-330	0 to 330Ω / 1A
ECO1/2-470	0 to 470Ω / 0.8A
ECO1/2-680	0 to 680Ω / 0.7A
ECO1/2-1000	0 to 1000Ω / 0.6A
ECO1/2-3300	0 to 3300Ω / 0.3A

Dim. : 270 x 92 x 163mm / 1.9kg

#### ECO2

Rheostats 1300W	
Ref.	VALUES
ECO2-0.5	0 to 0,5Ω / 50A
ECO2-1.6	0 to 1,6Ω / 28A
ECO2-5	0 to 5Ω / 16A
ECO2-11.5	0 to 11,5Ω / 10A
ECO2-16.5	0 to 16,5Ω / 8.7A
ECO2-23.4	0 to 23,4Ω / 7.2A
ECO2-33	0 to 33Ω / 6A
ECO2-50	0 to 50Ω / 5A
ECO2-106	0 to 106Ω / 3.3A
ECO2-165	0 to 165Ω / 2.8A
ECO2-500	0 to 500Ω / 1.6A
ECO2-1650	0 to 1650Ω / 0.9A
ECO2-5000	0 to 5kΩ / 0.5A

Dim. : 470 x 164 x 163mm / 5.5kg

#### ECO1

Rheostats 640W	
Ref.	VALUES
ECO1-1	0 to 1Ω / 25A
ECO1-3.3	0 to 3,3Ω / 14A
ECO1-4.7	0 to 4,7Ω / 12A
ECO1-6.8	0 to 6,8Ω / 10A
ECO1-10	0 to 10Ω / 8A
ECO1-15	0 to 15Ω / 6,5A
ECO1-25	0 to 25Ω / 5A
ECO1-33	0 to 33Ω / 4.4A
ECO1-50	0 to 50Ω / 3.6A
ECO1-68	0 to 68Ω / 3A
ECO1-150	0 to 150Ω / 2A
ECO1-210	0 to 210Ω / 1.7A
ECO1-650	0 to 650Ω / 1A
ECO1-1000	0 to 1000Ω / 0.8A
ECO1-1500	0 to 1500Ω / 0.65A
ECO1-2200	0 to 2200Ω / 0.54A
ECO1-4700	0 to 4700Ω / 0.37A
ECO1-10000	0 to 10kΩ / 0.25A

Dim. : 470 x 92 x 163mm / 3kg

#### ECO3

Rheostats 1900W	
ref.	VALUES
ECO3-0.33	0 to 0,33Ω / 76A
ECO3-1.1	0 to 1,1Ω / 42A
ECO3-3.3	0 to 3,3Ω / 24A
ECO3-11	0 to 11Ω / 13A
ECO3-33	0 to 33Ω / 7.6A
ECO3-110	0 to 110Ω / 4.2A
ECO3-333	0 to 333Ω / 2.4A
ECO3-1100	0 to 1100Ω / 1.4A
ECO3-3300	0 to 3300Ω / 0.76A

Dim. : 470 x 248 x 163mm / 8.3kg

### 3-PHASE RHEOSTAT (3 RESISTANCES)



Rheostats 1900W	
Ref	VALUES
ECOTRI-1	0 to 3 x 1Ω / 3 x 25A
ECOTRI-3.3	0 to 3 x 3,3Ω / 3 x 14A
ECOTRI-10	0 to 3 x 10Ω / 3 x 8A
ECOTRI-33	0 to 3 x 33Ω / 3 x 4.4A
ECOTRI-100	0 to 3 x 100Ω / 3 x 2.5A
ECOTRI-330	0 to 3 x 330Ω / 3 x 1.4A
ECOTRI-1000	0 to 3 x 1kΩ / 3 x 0.8A
ECOTRI-3300	0 to 3 x 3,3kΩ / 3 x 0.44A
ECOTRI-10000	0 to 3 x 10kΩ / 3 x 0.25A

Dim. : 470 x 248 x 163mm / 8.3kg

- There are 3 resistors inside this rheostat all insulated from each other
- One button allows the varying of the resistance of all of them simultaneously.
- Connected in star or delta, these rheostats act as a balanced 3-phase load.
- 9 safety terminals + 1 earth terminal.

## RHEOSTATS WITH 3 RANGES ACCORDING TO THE COUPLING

Ref.	MODE 1	MODE 2	MODE 3
SPECO-2	0 to 2Ω / 25A	0 to 1Ω / 25A	0 to 0.5Ω / 50A
SPECO-6	0 to 6.6Ω / 14A	0 to 3.3Ω / 14A	0 to 1.6Ω / 28A
SPECO-20	0 to 20Ω / 8A	0 to 10Ω / 8A	0 to 5Ω / 16A
SPECO-50	0 to 46Ω / 5A	0 to 23Ω / 5A	0 to 11.5Ω / 10A
SPECO-66	0 to 66Ω / 4.4A	0 to 33Ω / 4.4A	0 to 16.5Ω / 8.8A
SPECO-100	0 to 92Ω / 3.6A	0 to 46Ω / 3.6A	0 to 23Ω / 7.2A
SPECO-136	0 to 132Ω / 3A	0 to 66Ω / 3A	0 to 33Ω / 6A
SPECO-200	0 to 200Ω / 2.5A	0 to 100Ω / 2.5A	0 to 50Ω / 5A
SPECO-420	0 to 420Ω / 1.7A	0 to 210Ω / 1.7A	0 to 105Ω / 3.4A
SPECO-660	0 to 660Ω / 1.4A	0 to 330Ω / 1.4A	0 to 165Ω / 2.8A
SPECO-1,3K	0 to 1.3kΩ / 1A	0 to 650Ω / 1A	0 to 325Ω / 2A
SPECO-2K	0 to 2kΩ / 0.8A	0 to 1kΩ / 0.8A	0 to 500Ω / 1.6A
SPECO-6K	0 to 6.6kΩ / 0.44A	0 to 3.3kΩ / 0.44A	0 to 1.6kΩ / 0.9A
SPECO-20K	0 to 20kΩ / 0.25A	0 to 10kΩ / 0.25A	0 to 5kΩ / 0.5A

